



Conexión Hembra Giratoria JIC 90°

JIC 90° Cono 37°

REFERENCIA: NJ90T

CÓDIGO	REFERENCIA	MEDIDAS	ROSCA-E	A	C	H	S
PNJ90T 04-04	NJ90T 04-04	1/4" X 1/4"	7/16"X20	30	9	33.5	15
PNJ90T 04-05	NJ90T 04-05	1/4" X 5/16"	1/2"X20	30	9.5	34	17
PNJ90T 04-06	NJ90T 04-06	1/4" X 3/8"	9/16"X18	30	10.5	34	19
PNJ90T 06-06	NJ90T 06-06	3/8" X 3/8"	9/16"X18	35.3	10.5	39.3	19
PNJ90T 06-08	NJ90T 06-08	3/8" X 1/2"	3/4"X16	35.3	11	41.3	24
PNJ90T 06-10	NJ90T 06-10	3/8" X 5/8"	3/4"X16	56	11	51.5	24
PNJ90T 08-08	NJ90T 08-08	1/2" X 1/2"	3/4"X16	41	11	47	24
PNJ90T 08-10	NJ90T 08-10	1/2" X 5/8"	7/8"X14	56.5	11	51.5	27
PNJ90T 10-10	NJ90T 10-10	5/8" X 5/8"	7/8"X14	56.5	13	52.5	27
PNJ90T 10-12	NJ90T 10-12	5/8" X 3/4"	1.1/16"X12	56.5	15	54	32
PNJ90T 12-12	NJ90T 12-12	3/4" X 3/4"	1.1/16"X12	65.5	15	63.5	32
PNJ90T 12-16	NJ90T 12-16	3/4" X 1"	1.5/16"X12	65.5	16	63.5	41

E - Rosca

A - Longitud total desde el centro de la tuerca hasta el final de la espiga

C - Longitud de la espiga (la parte que entra la manguera)

S - El tamaño de la llave (en mm) que necesitas para apretar la tuerca